

INSTALLATION STEPS

PRE-INSTALLATION NOTES

1. Application area must be clean, dry and wax free
2. Ideal install temperature is above 60° F. During cold weather, warm the 3M tape and bumper surface for best adhesion.
3. Not recommended for use on painted bumpers.
4. Do not wash vehicle for 24 hours following installation.

TOOLS

Heat Gun or Hair Dryer • Measuring Tape • Masking Tape • Cleaning Cloth

STEP 1:

Wash install location thoroughly. Use provided alcohol pads to prep surface. Use masking tape as a guide. Make sure tape is straight and at desired location.



STEP 2:

Peel back red liner and attach gently. **NOTE: DO NOT PRESS DOWN FIRMLY UNTIL YOU ARE SATISFIED WITH THE POSITION OF THE BUMPER.**



STEP 3:

Press down firmly along edges for 10 seconds. Once attached, corner guard may be difficult to remove without damaging product.

